

## OVERVIEW

---

The Everbright is art you make art with—think the Lite-Brite of your childhood, but with ergonomic dials that rotate endlessly in either direction through a spectrum of hundreds of colors. The entire board resets with the press of a button, removing every obstacle to creativity. Made with evolutionary biology in mind, The Everbright considers the integration of the hands and eyes in the development of humankind and the ways in which people take in and manipulate the world around them. Since 2015, Hero Design has been exclusively making the Everbright in limited quantities for public spaces. Each Everbright is individually made to order in California.

## POWER

---

- When the Everbright is plugged in, it is powered on.
- An external light switch in your building is connected to your Everbright. Please power your Everbright off each night.
- After powering the board on, wait about 30 seconds for it to boot up. One of the interactive canvases should begin to play.
- You should see illuminated GREEN and BLUE function buttons on the top of the board, on the left-hand side.
- You should hear light whirring from the power supplies on the top of the board, which have integrated fans.

## 1. TURN ANY DIAL IN EITHER DIRECTION

---

- Turn any dial in either direction.
- After a period of inactivity, the board will refresh itself automatically.

## 2. PRESS BLUE BUTTON TO RESET

---

On the top of the board, on the left-hand side, it's the button on the right.

Clears your design from the board and resets the interactive canvas.

To clear your design, press-and-release the BLUE button for about 1 second.

## 3. PRESS GREEN BUTTON TO SWITCH CANVASES

---

On the top of the board, on the left-hand side, it's the button on the left.

Allows you to rotate between different interactive canvases, such as Classic Creativity, Starburst, and Color Flow.

Press-and-release the GREEN button for 1 second to change to a new interactive canvas.